Arm length 400mm
Maximum payload 4kg

■ Ordering method

YK400XGC-150

No entry: None F: With tool flange

Specify various controller setting items. RCX240/RCX240S ▶ P.532

h	RCX340-4-	-	-		-			
	Controller / Sumber of controllable axes	Safety - Option A (OP.A)	Option B — Option (OP.C)	C - Option D - Opti (OP.D) (OF	on E - Absolute P.E) battery			
	Specify various controller setting items. RCX340 ▶ P.542							
1	RCX240S	-	-	-	-			
	Controller - C	E Marking - Expans	sion I/O - Network opt	tion - iVY System -	Gripper - Battery			

Basic specifications									
		X axis	Y axis	Z axis	R axis				
Axis	Arm length (mm)	250	150	150	-				
specifications	Rotation angle (°)	+/-129	+/-144	_	+/-360				
AC servo motor output (W)		200	150	50	100				
Repeatability Note 1 (XYZ: mm) (R: °)		+/-0.01		+/-0.01	+/-0.004				
Maximum speed (XYZ: m/sec) (R: °/sec)		6.1		1.1	1020				
Maximum pa	ayload (kg)	4							
Standard cycl	e time: with 2kg payload (sec)Note 2	0.57							
R-axis toleral	ole moment of inertia Note 3 (kgm²)	0.05							
User wiring	(sq × wires)	0.2×10							
User tubing	(Outer diameter)	ф4×4							
Travel limit		1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)							
Robot cable	length (m)	Standard: 3.5 Option: 5, 10							
Weight (kg)		22.5							
Degree of cl	eanliness	ISO CLASS 3 (ISO 14644-1) Note 4+ESDNote 5							
Intake air (N	ℓ/min)	30 Note 6							

Note 1. This is the value at a constant ambient temperature. (X,Y axes)

Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion). Note 3. There are limits to acceleration coefficient settings. See P.608.

Note 4. Class 10 (0.1µm) equivalent to FED-STD-209D

Note 5. ESD (ElectroStatic Discharge) prevention is an option. Please contact our distributor.

Note 6. The necessary intake amount varies depending on the use conditions and environment.

Controller Controller Power capacity (VA) Operation method Programming / I/O point trace / RCX340 Remote command / 1000 RCX240S Operation using RS-232C communication

"Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.
The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)
See our robot manuals (installation manuals) for detailed integrating.

To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below http://global.yamaha-motor.com/business/robot/



