Rod type

CE compliance

N: With no brake

B: With brake

Origin on the non-motor side is selectable: Lead 6, 12

■ Ordering method

SR05 Lead : 12mm S: Straight model R:Space-saving model Note 1 (motor installed on right) : Space-saving model Not (motor installed on left)

Note 1. See P.129 for grease gun nozzles. Note 2. When "2mm lead" is selected, the origin position

reset. For details, refer to the manual.

cannot be changed (to non-motor side).

Note 3. If changing from the origin position at the time of purchase, the machine reference amount must be

Note 4. The robot cable is flexible and resists bending. Note 5. See P.498 for DIN rail mounting bracket.

Note 6. Select this selection when using the gateway function. For details, see P.60.

S2 PN: PNF GW: No I/O board[№] SH B: With batte PN: PNF (Absolute) (Incremental) SD

SR05-R

Basic specifications


Motor		56 Step motor		
Resolution (Pulse/rotation)		20480		
Repeatability (mm)		+/-0.02		
Deceleration mechanism		Ball screw \$12 (Class C10)		
Ball screw lead (mm)		12	6	2
Maximum speed Note 1 (mm/sec)		300	150	50
Maximum	Horizontal	50	55	60
payload (kg)	Vertical	10	20	30
Max. pressing force (N)		250	550	900
Stroke (mm)		50 to 300 (50pitch)		
Lost motion		0.1mm or less		
Rotating backlash (°)		+/-1.0		
Overall length	Horizontal	Stroke+276		
(mm)	Vertical		Stroke+316	3
Maximum outside dimension of body cross-section (mm)		W56.4 × H71		
Cable length (m)		Standard: 1 / Option: 3, 5, 10		


Note 1. The maximum speed needs to be changed in accordance with the payload.

See the "Speed vs. payload" graph shown on the right. For details, see P. 128.

Speed vs. payload

N: Standard Note 3
Z: Non-motor side





Running life

5000 km on models other than shown below.

SR05-S


Cable length N

Stroke

(50mm pitch)

50 to 300

Running life of only the model shown below becomes shorter than 5000 km depending on the payload, so check the running life curve.



Note. See P.129 for running life distance to life time conversion

Motor installation (Space-saving model)





Controller

Controller	Operation method	(
TS-S2	I/O point trace /	Т
TS-SH	Remote command	 _

Controller	Operation method
TS-SD	Pulse train control

